

C L E A N F I R E S Y S T E M

XARALYN®

Bioethanol freestanding fireplace Stoove



The safest open fire



Version: 2024-01

EN IMPORTANT SAFETY INFORMATION

The bioethanol Stoove operates without the need for a chimney or air vents. Instead, bioethanol fuel is poured into a burner containing a ceramic core. Once ignited, the fuel burns slowly, providing a clean and efficient flame.

Unlike traditional stoves, the Stoove draws oxygen from the surrounding air at ambient levels, making it sensitive to draughts. Properly functioning bioethanol stove emits only heat and minimal CO₂, ensuring high efficiency and eco-friendliness.



The Stoove can become extremely hot and provides a comforting warmth. Avoid touching the Stoove after ignition to prevent burns. Ensure safety by carefully following the instructions below.

PLACING THE STOOVE


To ensure safety:

- Curtains, carpets, sofas, or any other high combustible items/walls must be kept at least 500 mm away from the Stoove.

POSITIONING THE STOOVE

The Stoove should not be placed directly on a flammable surface, such as wood, carpet, or a cast floor. If positioning it on such a surface is unavoidable, use a non-flammable plate underneath to protect the floor.

Note: Xaralyn is not responsible for floor/wall damage caused by incorrect use of the Stoove.



**recommended on a flammable underground*

WITH OR WITHOUT DECO CHIMNEY

This bioethanol Stoove does not require a chimney to function. However, many people opt to add a decorative pipe for a more traditional stove appearance.



Using the decorative pipe

- **Ensure** the pipe is placed against a non-combustible wall, such as concrete.
- **DO NOT** use the decorative pipe near wallpapered or other combustible walls.
- **Important:** High temperatures may cause the pipe to adhere/melt to the Stoove. While this is normal, removing the pipe might damage the finish of the fireplace.
- **Decide beforehand** whether you want to use the Stoove with or without the decorative pipe.

IMPORTANT:

Due to the high temperatures, the pipe can become attached to the Stove. This is normal, but removing it could cause damage to the fireplace's finish. Therefore, decide in advance whether you want to use the Stove with the decorative pipe.

WARNING



DO NOT position the Stoove near combustible items. Keep at least 500 mm distance.



DO NOT touch the flames, metal or glass when the Stoove is hot. This can cause serious burns!



DO NOT allow children and pets to come close to the Stoove when the fireplace is hot.



DO NOT place items or objects on the Stoove!



Attention: Before using the burner, we recommend reading the burner manual.